## **Technical Data Sheet**

© KROHNE 11/2006

CMD

7.02541.22.00



# **OPTISWITCH 3000 series** Vibration level switch

for solids

- Highly robust tuning fork
- Insensitive to build-up
- Set-up without filling
- Detection of solids in water
- Maintenance-free

Electromagnetic flowmeters Variable area flowmeters Mass flowmeters Ultrasonic flowmeters Vortex flowmeters Flow controllers **Level measuring instruments** Pressure and temperature Heat metering Communications technology Switches, counters, displays and recorders Engineering systems & solutions

## Contents

1	Description of the measuring principle	3		
2	Type overview	5		
3	Mounting instructions	7		
4 Electrical connection				
5	<ul> <li>4.1 Preparing the connection</li></ul>			
6	5.1       Adjustment, general       1         5.2       Recurring function test - NAMUR electronics       1         5.3       Recurring function test - Two-wire electronics       1         Technical data       1         Dimensions       1	11 11 <b>13</b>		

#### Take note of safety instructions for Ex applications



Please note the Ex specific safety information which you will find on our homepage www.krohne-mar.com and which come with the appropriate instrument. In hazardous areas you should take note of the appropriate regulations, conformity and type approval certificates of the sensors and power supply units. The sensors must only be operated on intrinsically safe circuits. The permissible electrical values are stated in the certificate.

## 1 Description of the measuring principle

#### Measuring principle

OPTISWITCH is a level sensor with tuning fork for level detection.

It is designed for industrial use in all areas of process technology and is preferably used for bulk solids.

The vibrating element (tuning fork) is energized piezoelectrically and vibrates at its mechanical resonance frequency. The piezos are fixed mechanically and are hence not subject to temperature shock limitations. If the vibrating element is submerged in the product, the vibrating amplitude changes. This change is detected by the integrated oscillator and converted into a switching command.

Typical applications are overfill and dry run protection. Thanks to its simple and robust measuring system, OPTISWITCH is virtually unaffected by the chemical and physical properties of the bulk solid.

It functions even when exposed to strong external vibration or changing products.

#### Fault monitoring

The electronics of OPTISWITCH continuously monitors the following criteria:

- Correct vibrating frequency
- Line break to the piezo drive

If one of the stated malfunctions is detected or in case of power failure, the electronics takes on a defined switching condition, e.g. the relay deenergises (safe condition).

#### Solid detection in water

With the OPTISWITCH (3100 C, 3200 C, 3300 C) version for solid detection in water (option), the vibrating element is adjusted to the density of water. If submerged in water (density 1 g/cm<sup>3</sup>), OPTIS-WITCH signals "uncovered". Only if the vibrating element is also covered with solids (e.g. sand, sludge, etc.) will the sensor signal "covered".

### OPTISWITCH 3100 C, 3200 C, 3300 C

OPTISWITCH3100 C, 3200 C and 3300 C level switches are available in standard, cable and tube version and, thanks to the large array of process fittings, offer the optimal solution for any application. They are completely manufactured of stainless steel and have all standard approvals.

OPTISWITCH are virtually unaffected by product properties and must hence not be adjusted.

The level switches can be used in applications with process temperatures up to 250  $^\circ\text{C}$  (482  $^\circ\text{F})$  and pressures of up to 16 bar (232 psi).

You can detect bulk solids up to >0.008 g/cm<sup>3</sup> (0.0003 lbs/in<sup>3</sup>).

### **OPTISWITCH 3000 C**

OPTISWITCH 3000 C differs from the OPTISWITCH 3100 C, 3200 C and 3300 C level switches in its simple process fitting of plastic and the limited selection options. It is suitable for bulk solids from >0.08 g/cm<sup>3</sup> (0.003 lbs/in<sup>3</sup>).

OPTISWITCH 3000 C is only available as screwed version with plastic housing and without approvals.

The most important advantage of this instrument is its price, which makes the measurement loop very cost-effective.

### 1.1 Application examples

#### **Plastic processing**




Fig. 1: Level detection in a silo storing plastic granules

A large number of finished products are produced in the chemical industry as powder, granules or pellets. Plastic granules and powder are often stored in high narrow silos which are filled pneumatically.

Vibrating level switches like OPTISWITCH have proven over the past years in the level detection of plastics. Even with smallest bulk densities of only 20 g/l and changing products, the instruments deliver always precise results.

Advantages:

- Tuning fork suitable down to a density <20 g/l (e.g. Aerosils)
- Product-independent switching point
- Setup without filling

### **Building material industry**




Fig. 2: Silo for aggregate in the building material industry

Cement or aggregates are placed in interim storage in multiple chamber silos. When the chambers are filled, large quantities of dust are generated. Depending on the consistency of the aggregate, different material cones are formed and the product properties can change from filling to filling.


OPTISWITCH offers additional protection against overfilling the aggregate silo. The flexible suspension cable avoids mechanical strain caused by movements of the bulk solid. A filling is not necessary for setup. Because OPTISWITCH has practically no moving parts, it is not subject to wear.

Advantages:

- very rugged tuning fork
- High abrasion resistance
- insensitive to buildup
- Setup without filling


KROHNE

## 2 Type overview



	11
Preferred application:	Solids
Length:	-
Process fitting:	Thread G11/2A
Process temperature:	-50 +100 °C (-58 +212 °F)
Process pressure:	-1 6 bar/-100 600 kPa (-14.5 232 psi)
Signal output:	Relay, transistor, two-wire output, contactless electronic switch
Ruggedness	+
Sensitivity	-
Buildup	++
Installation length	+

KROHNE



## 3 Mounting instructions

#### Switching point

In general, OPTISWITCH can be mounted in any position. The instrument must be mounted in such a way that the vibrating element is at the height of the requested switching point.

The only exception is the mounting of the tuning fork vertically from the bottom. In this position it can happen that product sticks between the fork tines.

#### Socket

The vibrating element should protrude into the vessel to avoid buildup. For that reason, avoid using mounting bosses for flanges and screwed fittings. This applies particularly for horizontal installation and with adhesive products.

#### **Filling opening**

Install the instrument in such a way that the vibrating element does not protrude directly into the filling stream. Should such an installation location be necessary, mount a suitable baffle above or in front of the vibrating element, e.g. L80x8 DIN 1028 (see Fig. Part "a."). In abrasive solids, mounting according to fig. Part "b." has proven to be a good solution. The mound that forms in the concave baffle protects it from abrasion.




Fig. 3: Horizontal installation

- a. Convex mounting
- b. Concave mounting

#### Inflowing medium

If OPTISWITCH is mounted in the filling stream, unwanted switching signals may be generated. Mount OPTISWITCH at a location in the vessel where no disturbing influence from e.g. filling openings, agitators etc. can occur.




Fig. 4: Inflowing medium

#### Horizontal installation

To achieve a very precise switching point, you can install OPTIS-WITCH horizontally. However, if the switching point can have a tolerance of a few centimeters, we recommend mounting OPTIS-WITCH approx. 20° inclined to the vessel bottom to avoid buildup.

Turn the tuning fork of OPTISWITCH 3000 in such a way that no product is left on the fork surface. To direct the fork, there is a marking on the hexagon of the thread. Make sure that the marking points upward.

#### Material cone

In silos containing solids, material cones can form which change the switching point. Please keep this in mind when installing the sensor in the vessel. We recommend selecting an installation location where the vibrating element detects an average value of the material cone.

The vibrating element must be mounted at a location that takes the arrangement of the filling and emptying apertures into account.

To compensate measurement errors caused by the material cone in cylindrical vessels, the sensor must be mounted at a distance of d/6 from the vessel wall.




Fig. 5: Filling and emptying centered




Fig. 6: Filling in the center, emptying laterally

- 1 OPTISWITCH
- 2 Emptying opening
- 3 Filling opening

#### **Tensile load**

With cable version, make sure that the max. permissible tensile load of the suspension cable is not exceeded. The danger of this happening exists particularly with very heavy solids and large meas. lengths. The max. permissible load is stated in chapter "*Technical data*".

#### Agitators

Filling or extraction forces, equipment vibration, or similar, can subject the level switch to strong lateral forces. For this reason, do not use an overly long extension tube for OPTISWITCH, but check if you can mount an OPTISWITCH 3000 C or 3100 C level switch on the side of the vessel in horizontal position.

Extreme vibration caused by the process or the equipment, e.g. by fluidization or beaters in the vessel, can cause the extension tube of OPTISWITCH to vibrate in resonance. This leads to increased stress on the upper weld joint. Should a longer tube version be necessary, you can provide a suitable support or guy directly above the vibrating element to secure the extension tube.



This measure applies particularly to applications in Ex areas. Make sure that the tube is not subjected to bending forces through this measure.

Should the installation from top be necessary, check if you can use a cable version.

In the long run, strong vibrations can damage the instrument electronics. With a remote housing these can be disonnected from the process.

#### Flows

To minimise flow resistance caused by the tuning fork, OPTIS-WITCH should be mounted in such a way that the surfaces of the blades are parallel to the product movement.



Fig. 7: Orientation of the tuning fork in case of flow

- 1 Marking with screwed version
- 2 Direction of flow

#### Lock fitting

OPTISWITCH in tube version can be mounted with a lock fitting for height adjustment. Take note of the pressure specifications of the lock fitting.

#### Baffle protection against falling rocks

In applications such as grit chambers or settling basins for coarse sediments, the vibrating element must be protected against damage with a suitable baffle.




Fig. 8: Baffle protection against damages

#### Pressure/Vacuum

The process fitting must be sealed if there is gauge or low pressure in the vessel. Check if the seal material is resistant against the measured product and the process temperature.

## 4 Electrical connection

### 4.1 Preparing the connection

#### Note safety instructions

Generally note the following safety instructions:
Connect only in the complete absence of line voltage

Take note of safety instructions for Ex applications



In hazardous areas you should take note of the appropriate regulations, conformity and type approval certificates of the sensors and power supply units.

#### Select power supply

Connect the power supply according to the following diagrams. Oscillators with relay output and contactless electronic switch are designed in protection class 1. To maintain this protection class, it is absolutely necessary that the ground conductor be connected to the internal ground terminal. Take note of the general installation regulations. As a rule, connect OPTISWITCH to vessel ground (PA), or in case of plastic vessels, to the next ground potential. On the side of the housing there is a ground terminal between the cable entries. This connection serves to drain off electrostatic charges. In Ex applications, the installation regulations for hazardous areas must be given priority.

The data for power supply are stated in the "*Technical data*" in the "*Supplement*".

#### Selecting connection cable

The instrument is connected with standard cable with round cross section. An outer cable diameter of 5  $\dots$  9 mm (0.2  $\dots$  0.35 in) ensures the seal effect of the cable gland.

If cable with a different diameter or wire cross section is used, exchange the seal or use an appropriate cable connection.



In hazardous areas, only use approved cable connections for OPTISWITCH.

### Select connection cable for Ex applications



Take note of the corresponding installation regulations for Ex applications.

## 4.2 Wiring plan

#### **Relay output**

We recommend connecting OPTISWITCH in such a way that the switching circuit is open when there is a level signal, line break or failure (safe condition).

The relays are always shown in non-operative condition.




Fig. 9: Wiring plan, single chamber housing

- 1 Relay output
- 2 Relay output
- 3 Voltage supply

#### **Transistor output**

We recommend connecting OPTISWITCH in such a way that the switching circuit is open when there is a level signal, line break or failure (safe condition).

The instrument is used to control relays, contactors, magnet valves, warning lights, horns as well as PLC inputs.




Fig. 10: Wiring plan, single chamber housing




Fig. 11: NPN action




Fig. 12: PNP action

#### **Contactless electronic switch**

We recommend connecting OPTISWITCH in such a way that the switching circuit is open when there is a level signal, line break or failure (safe condition).

The contactless electronic switch is always shown in non-operative condition.

The instrument is used for direct control of relays, contactors, magnet valves, warning lights, horns etc. It must not be operated without an intermediately connected load, because the electronics would be destroyed if connected directly to the mains. It is not suitable for connection to low voltage PLC inputs.

Domestic current is temporarily lowered below 1 mA after switching off the load so that contactors, whose holding current is lower than the constant domestic current of the electronics, are reliably switched off.

When OPTISWITCH is used as part of an overfill protection system according to WHG, also note the regulations of the general type approval.




Fig. 13: Wiring plan, single chamber housing

1 Screening

#### Two-wire output

We recommend connecting OPTISWITCH in such a way that the switching circuit is open when there is a level signal, line break or failure (safe condition).

For connection to an SU 501 signal conditioning instrument dto. Ex. The sensor is powered by the connected signal conditioning instrument. Further information is available in chapter "*Technical data*" in the "*Supplement*", "*Ex-technical data*" are available in the supplied "*Safety information manual*". Take note of the operating instructions manual of the signal conditioning instrument. Suitable signal conditioning instruments are listed in chapter "*Technical data*".




Fig. 14: Wiring plan, single chamber housing

1 Voltage supply

#### NAMUR output

For connection to an amplifier according to NAMUR (IEC 60947-5-6, EN 50227). For further information see chapter "*Technical data*".




Fig. 15: Wiring plan, single chamber housing

#### 5 Operation

#### 5.1 Adjustment, general




Fig. 16: Adjustment elements electronics module, e.g. relay output (VB60R)

- Potentiometer for switching point adaptation (not with OPTISWITCH 3000 C) 1
- DIL switch for mode adjustment 2
- З Ground terminal
- 4 Screwed terminals
- 5 Control lamp

#### Switching point adaptation (1) OPTISWITCH 3100 C, 3200 C, 3300 C

You can adapt the switching point of OPTISWITCH to the solid with the potentiometer. The switching point is preset and covered by a label. It must only be modified in special cases.

OPTISWITCHs with tuning fork are preset to a product density of >0.02 g/cm<sup>3</sup> (0.0007 lbs/ in<sup>3</sup>). In very light solids, turn the potentiometer to complete left position 0.008 ... 0.1 g/cm<sup>3</sup>) (0.0003 ... 0.0036 lbs/in<sup>3</sup>). By doing this, the tuning fork will be more sensitive and can detect very light solids, such as e.g. Aerosils more reliably.

#### **OPTISWITCH 3000 C**

OPTISWITCH 3000 C can detect bulk solids from a product density of >0.08 g/cm<sup>3</sup> (0.003 lbs/in<sup>3</sup>).

#### Mode adjustment (2)

With the mode adjustment (min./max.) you can change the switching condition of the output. You can set the required mode (max. - max. detection or overfill protection, min. - min. detection or dry run protection).

#### Signal lamp (5)

Diode for indication of the switching status.

#### **Recurring function test - NAMUR elec-**5.2 tronics

According to IEC 61508.

#### SIL

OPTISWITCH is gualified in mode A (overfill protection) for use in measuring chains of stage SIL2 according to IEC 61508 (redundant, stage SIL3).

You find the "Safety Manual" with detailed specification on SIL on our website.

#### **Recurring function test**

The recurring test according to IEC 61508 can be carried out by pushing the simulation key on the oscillator or by briefly (>2 seconds) interrupting the supply to the sensor. The correct sequence of the switching conditions must be monitored via the switching amplifier as well as the connected systems. The sensor must neither be removed nor a response triggered by filling the vessel. You can carry out the function test with the outputted current values also directly via a safety PLC or a process control system. Simulation key on the electronics module

OPTISWITCH has an integrated simulation key. The simulation key is lowered on the electronics module. Push the simulation key for >2 seconds.

If OPTISWITCH is connected to an SPLC, you have to interrupt the connection cable to the sensor for >2 seconds.

After releasing the simulation key or briefly interrupting the connection cable to the sensor, you can check the complete measuring system on correct function. A switching procedure is simulated during the test.




Fig. 17: Flow chart of the function test

Full signal

2 Empty signal

Check if all the switching conditions occur in the correct sequence and the stated time period. If this is not the case, there is a fault in the measuring system. Keep in mind that connected instruments are activated during the function test. This allows you to check the correct function of the measuring system.

#### 5.3 Recurring function test - Two-wire electronics

According to IEC 61508.

#### SIL

OPTISWITCH in conjunction with a suitable signal conditioning instruments is gualified in mode A (overfill protection) for use in measuring chains of stage SIL2 according to IEC 61508 (redundant, stage SIL3).

You find the "Safety Manual" with detailed specification on SIL on our website.

#### **Recurring function test**

The recurring test according to IEC 61508 can be carried out by pushing the test key on the signal conditioning instrument or by briefly (>2 seconds) interrupting the supply to the sensor. The correct sequence of the switching conditions must be monitored via the two LEDs on the signal conditioning instrument as well as the connected systems. The sensor must neither be removed nor a response triggered by filling the vessel.

You can carry out the function test with the outputted current values also directly via a safety PLC or a process control system. The implementation and switching sequence of the function test is described also in the operating instructions manual of the appropriate signal conditioning instrument.

#### Test key on the signal conditioning instrument

The signal conditioning instrument has an integrated test key. The test key is lowered in the front plate of the signal conditioning instrument. Push the test key with a suitable object (e.g. screw-driver, pen etc.) for >2 seconds.

If OPTISWITCH is connected to an SPLC, you have to interrupt the connection cable to the sensor for >2 seconds.

After releasing the test key or interrupting the connection cable to the sensor, the complete measuring system can be checked on correct function. The following operating conditions are simulated during the test:

- Fault signal
- Empty signal
- Full signal




Fig. 18: Flow chart of the function test

- 1 Full signal
- 2 Empty signal

Check if all the switching conditions occur in the correct sequence and the stated time period. If this is not the case, there is a fault in the measuring system. Keep in mind that connected instruments are activated during the function test. This allows you to check the correct function of the measuring system.

#### **Technical data** 6

#### **General data**

Material 316L corresponds to 1.4404 or 1.4435

### **OPTISWITCH 3000 C**

- Materials, wetted parts - Process fitting - thread PBT vibrating element Materials, non-wetted parts - Housing - Seal ring between housing and housing cover Silicone Ground terminal Weight Max. lateral load **OPTISWITCH 3100 C** Materials, wetted parts - Process fitting - thread 316L - Process fitting - flange 316L - Seal - vibrating element 316L - Extension tube (OPTISWITCH 3300 C) ø 43 mm (1.7 in) 316L Materials, non-wetted parts Housing - Seal ring between housing and housing cover - Ground terminal Weights - OPTISWITCH 3100 C with plastic housing - OPTISWITCH 3100 C with Aluminium housing - OPTISWITCH 3100 C with stainless steel housing Max. lateral load **OPTISWITCH 3200 C** Materials, wetted parts - Process fitting - thread 316L - Process fitting - flange 316L - Seal CR, CSM - vibrating element 316L - Suspension cable PUR Materials, non-wetted parts Housing - Seal ring between housing and housing cover - Ground terminal Weights - OPTISWITCH 3200 C with plastic housing 1500 g (53 oz) - OPTISWITCH 3200 C with Aluminium housing - OPTISWITCH 3200 C with stainless steel Suspension cable Max. permissible tensile load Sensor length **OPTISWITCH 3300 C** Materials, wetted parts
- Process fitting thread
- Process fitting flange
- Seal
- vibrating element
- Extension tube (OPTISWITCH 3300 C) ø 43 mm (1.7 in) Materials, non-wetted parts
- Housing
- Seal ring between housing and housing cover
- Ground terminal

316L/318S13 (1.4462)

plastic PBT (Polyester) 316Ti/316L 1150 g (40 oz) 600 N (135 lbf)

Klingersil C-4400

Plastic PBT (Polyester), Alu die-casting powder-coated, 316L NBR (stainless steel housing), silicone (Alu/plastic housing) 316Ti/316L

1500 g (53 oz) 1950 g (69 oz) 2300 g (81 oz) 600 N (135 lbf)

Plastic PBT (Polyester), Alu die-casting powder-coated, 316L NBR (stainless steel housing), silicone (Alu/plastic housing) 316Ti/316L

1950 g (69 oz) 2300 g (81 oz) approx. 165 g/m (1.8 oz/ft) 3000 N (675 lbs) 0,3 ... 80 m (1 ... 262 ft)

316L 316L Klingersil C-4400 316L 316L

Plastic PBT (Polyester), Alu die-casting powder-coated, 316L NBR (stainless steel housing), silicone (Alu/plastic housing) 316Ti/316L

Weights

- OPTISWITCH 3300 C with plastic housing
- OPTISWITCH 3300 C with Aluminium housing
- OPTISWITCH 3300 C with stainless steel housing
- Extension tube (OPTISWITCH 3300 C) ø 43 mm (1.7 in) Sensor length
- Max. lateral load Max. lateral load
- OPTISWITCH 3300 C

#### **Output variable**

Relay output Output Turn-on voltage - min. - max. Switching current - min. - max. Breaking capacity - max. Contact material (relay contacts) Modes (adjustable) Delay time - when immersed - when laid bare

#### Transistor output Output

Load current Turn-on voltage Blocking current Modes (adjustable) Delay time – when immersed – when laid bare

#### Contactless electronic switch Output

Modes (adjustable) Delay time – when immersed – when laid bare

## Two-wire output

Output

Suitable signal conditioning instruments Output signal – Mode min.

```
- Mode max.
```

Fault signal
Modes (adjustable)
Delay time
when immersed
when laid bare

NAMUR output Output 1500 g (53 oz) 1950 g (69 oz) 2300 g (81 oz) approx. 2000 g/m (21.5 oz/ft) 0.3 ... 6 m (1 ... 20 ft) 290 Nm (214 lbf ft), max. 600 N (135 lbf)

290 Nm (214 lbf ft), max. 600 N (135 lbf)

relay output (DPDT), 2 floating spdts

10 mV 253 V AC, 253 V DC

10 μΑ 5 A AC, 1 A DC

1250 VA, 50 W AgCdO and Au plated min./max.

approx. 0.5 s approx. 1 s

floating transistor output, overload and permanently shortcircuit proof

max. 400 mA max. 55 V DC <100 μA min./max.

approx. 0.5 s approx. 1 s

#### Contactless electronic switch

min./max.

approx. 0.5 s approx. 1 s

Two-wire output

SU 501

Vibrating element uncovered: 16 mA ±1 mA, vibrating element covered: 8 mA ±1 mA Vibrating element uncovered: 8 mA ±1 mA, vibrating element covered: 16 mA ±1 mA <2 mA min./max.

approx. 0.5 s approx. 1 s

Two-wire NAMUR output

KROHNE

bient conditions Ambient temperature on the housing	-40 +70 °C (-40 +158 °F)	
– max.	falling characteristics (Low current when immersed)	
– min.	rising characteristics (High current when immersed)	
Modes (NAMUR output adjustable to falling or rising characteristics)		
	DIN 19234)	
Necessary processing system	NAMUR processing system according to IEC 60947-5-6 (EN 50227/	
<ul> <li>Fault signal</li> </ul>	≤1 mA	
<ul> <li>Rising characteristics (min.)</li> </ul>	≤1 mA uncovered/≥2.2 mA covered	
<ul> <li>Falling characteristics (max.)</li> </ul>	≥2.2 mA uncovered/≤1 mA covered	
Current consumption		

Ambient temperature on the housing Storage and transport temperature

#### **Process conditions**

Parameter

#### **OPTISWITCH 3000 C**

Process pressure Process temperature OPTISWITCH of 316L Density Granular size

#### OPTISWITCH 3100 C, 3300 C Parameter

Process pressure

Process temperature OPTISWITCH of 316L Process temperature (thread or flange temperature) with temperature adapter (option) Limit level of solids

-40 ... +80 °C (-40 ... +176 °F)

-1 ... 6 bar/-100 ... 600 kPa (-14.5 ... 87 psi) with PN 40 -50 ... 100 °C (-58 ... +212 °F) >0.08 g/cm<sup>3</sup> (0.003 lbs/in<sup>3</sup>) ø max. 15 mm (0.6 in)

Limit level of solids

-1 ... 25 bar/-100 ... 2500 kPa (-14.5 ... 363 psi) with PN 40 -50 ... 150 °C (-58 ... 302 °F) -50 ... 250 °C (-58 ... 482 °F)




Fig. 19: Ambient temperature - Product temperature

- 1 Product temperature
- 2 Ambient temperature

3 Temperature range with temperature adapter

Density

Granular size

## OPTISWITCH 3200 C

Parameter

Process pressure Process temperature OPTISWITCH of 316L Density Granular size

#### >0.008 g/cm<sup>3</sup> (0.0003 lbs/in<sup>3</sup>) ø max. 15 mm (0.6 in)

Limit level of solids

-1 ... 6 bar/-100 ... 600 kPa (-14.5 ... 87 psi) with PN 40 -20 ... +80 °C (-4 ... +176 °F) >0.008 g/cm<sup>3</sup> (0.0003 lbs/in<sup>3</sup>) ø max. 15 mm (0.6 in)

Electromechanical data

Cable entry/plug (dependent on the version)

Single chamber housing

 1x cable entry M20x1.5 (cable-ø 5 ... 9 mm), 1x blind stopper M20x1.5; attached 1x cable entry M20x1.5

	<ul> <li>or:</li> <li>1x cable entry ½ NPT, 1x blind stopper ½ NPT, 1x cable entry ½ NPT</li> <li>or:</li> <li>1x plug M12x1, 1x blind stopper M20x1.5</li> </ul>
Spring-loaded terminals	for wire cross-section up to 1.5 mm <sup>2</sup>

#### Adjustment elements

– min.	Min. detection or dry run protection
– max.	Max. detection or overfill protection
Electronics version - two-wire output	
Mode switch	
– min.	Vibrating element uncovered: 16 mA $\pm$ 1 mA Vibrating element unc 8 mA $\pm$ 1 mA
– max.	Vibrating element uncovered: 8 mA $\pm$ 1 mA Vibrating element cov 16 mA $\pm$ 1 mA
Electronics version - NAMUR output	
Mode switch	
– min.	rising characteristics (High current when immersed)
– max.	falling characteristics (Low current when immersed)

Relay output	
Supply voltage	20 253 V AC, 50/60 Hz, 20 72 V DC (at U >60 V DC, the ambient temperature can be max. 50 °C/122 °F)
Power consumption	1 8 VA (AC), approx. 1.3 W (DC)
Transistor output	
Supply voltage	10 55 V DC
Power consumption	max. 0.5 W
Contactless electronic switch	
Supply voltage	20 253 V AC, 50/60 Hz, 20 253 V DC
Domestic current requirement Load current	approx. 3 mA (via load circuit)
– min.	10 mA
– max.	400 mA (at I >300 mA the ambient temperature can be max. 60 °C/140 °F) max. 4 A up to 40 ms
Two-wire output	
Supply voltage	10 36 V DC (via the signal conditioning instrument)
NAMUR output	
Supply voltage (standard characteristics)	for connection to amplifier according to NAMUR IEC 60947-5-6, approx. 8.2 V
Open-circuit voltage	U <sub>o</sub> approx. 8.2 V
Shortcircuit current	I <sub>U</sub> approx. 8.2 mA

### **Electrical protective measures**

Electronics versions - relay output, contactless electronic switch				
Protection	IP 66/IP 67			
Overvoltage category	III			
Protection class	I			
Electronics versions - Transistor, two-wire, NAMUR output				
Protection	IP 66/IP 67			
Overvoltage category	111			

Protection class

II

### Approvals

#### **OPTISWITCH 3000 C**

OPTISWITCH 3000 C has no approvals.

 $\label{eq:optimal_op$ 

ATEX II 1/2 D IP66 T

OPTISWITCH 3100 C, 3200 C, 3300 C, electronics version - two-wire output ATEX II 1G, 1/2G, 2G EEx ia IIC T6

ATEX II 1G, 1/2G, 2G EEx ia IIC T6 + ATEX II 1/2 D IP66 T6 ATEX II 1/2G, 2G EEx d IIC T6 ATEX II 1/2 D IP66 T

#### **CE conformity**

Electronics versions - Relay, transistor, two-wire, NAMUR output EMVG (89/336/EWG), Emission: EN 61326: 1997 (class B), Susceptibility: EN 61326: 1997/A1: 1998

NSR (73/23/EWG), EN 61010-1: 2001

Electronics version - contactless electronic switch EMVG (89/336/EWG), Emission: EN 61326/A1: 1998 (class B), Susceptibility: EN 61326: 1997/A1: 1998

NSR (73/23/EWG), EN 61010-1: 2001

#### SIL conformity

OPTISWITCH fulfills the requirements of functional safety according to IEC 61508. You can find further information in the "Safety Manual OPTISWITCH".

#### **Dimensions** 7

### Housing




Fig. 20: Housing versions (OPTISWITCH 3000 C only with plastic housing)

- 1
- Plastic housing Stainless steel housing 2
- З Aluminium housing

#### **OPTISWITCH 3000 C**




Fig. 21: OPTISWITCH 3000 C, threaded version G11/2

#### **OPTISWITCH 3100 C**




Fig. 22: OPTISWITCH 3100 C, Screwed version G11/2

### **OPTISWITCH 3200 C**




Fig. 23: OPTISWITCH 3200 C, Screwed version G11/2

### **OPTISWITCH 3300 C**




Fig. 24: OPTISWITCH 3300 C, threaded version G11/2

### Temperature adapter




Fig. 25: Temperature adapter (only for OPTISWITCH 3100 C and 3200 C)